

Marking on PASCLUB

Connecting the PASCLUB and synchronisation.

1. Connect the GPS and GSM Antenna to the back of the PASCLUB and then connect and switch on the power supply.
2. Position the GPS antenna near a window and wait for a signal for both GPS and GSM to appear.
3. The Club Responsible can now log in to PAS-LIVE (www.pas-live.com) Username/password and very important the country MUST be changed to United Kingdom, via a Mobile, tablet, MAC or PC.
4. Once the Orange light has gone out on the PASCLUB a signal has been found.
5. On the PAS-LIVE Click on the PASCLUB (master) ICON along the top. This opens the PASCLUB and then click on the activation code.
6. A six-digit code will appear this needs to be entered into the PASCLUB. If this code is not entered, you cannot mark for races or readouts via the PAS-CLUB.
7. One the PAS-LIVE the standby button should have turned from Red to Green which means the PASCLUB is working correctly and connected to the cloud.
8. Next to the activation code button on PAS-LIVE you will see a PDF icon. Once the code is entered and the standby light is green if you click on the PDF ICON this will produce a secure PDF of the PASCLUB synchronisation which can be printed directly from your device via any printer.
9. A printout is required under Union rules before basketing and before readouts. The most recent synchronisation is at the top.

Setting up a race

1. The Club responsible can now on the PAS-LIVE web or PAS-LIVE App page click on the Open page Icon along the top and then click the + button to add a new race.
2. Select the Race point from the drop down or + button to add a New race point.
3. Add in the race code
4. For the Long/Lat Co-Ordinates enter 000000.0 for although this should be defaulted if the race is not new.
5. Fill in the basketing date and the proposed Release date.
6. Change the Price count to 1/1 to read all the pigeons on the result.
7. Click the Category for Example The top one Old /Yearling.
8. Tick the Category in the race for example the CAT old/yearling.
9. Click the Save Button.
10. Click the Master Icon on the homepage and then click back on the open page icon and the race should now show in the list.
11. Click on the pencil edit button next to the race and then add a release time. This can be adjusted to the correct release time afterwards, change the Price count to 1/1 to read all pigeons on the result.
12. Press Save
13. Click back on the PASCLUB Icon and next to PASCLUB picture click on the PDF to open the synchronisation sheet to be printed.

Race Marking on the PASCLUB

1. Once the race is set up as above, the PASCLUB is now ready for marking. Click on the basket icon on the PASCLUB master.
2. The PASCLUB will now connect to the PAS CLOUD and find the corresponding race.
3. If the clock is a Bricon SPD,SPX, SPXXL, connect via the top docking port as normal and follow the instructions.
4. For PASBOX press OK and then race mark pigeons. The ring will be sent to the cloud and will connect directly to the fanciers PASBOX at the loft
5. For other brands of ETS via Unives Press 2 connect the cable via the Port on the side and follow the instructions.
6. The PASCLUB will get fanciers details. If this clock has not been connected or the PAS cloud before or has been amended, then before you can basket the clock information has to be sent to the PAS-CLOUD as follows.
7. Press C and go back to the icon screen and move across to the up/down arrow pigeons to and from the cloud. Press OK and press 1 to send the clock details to the cloud.
8. Once the details are added to the cloud you can then return to basket and follow the instructions for basketing the pigeons via the screen.
9. If the club responsible clicks on the OPEN button on the PAS-LIVE screen then the race marking can be followed on a larger screen.
10. Once basketing is complete you can press C to stop and once the clock is deactivated if you wish to print via a parallel ETS connection printer. Give the printer time to print maybe 60 seconds. If it does not print press 7 and the number of copies you require. These will then print out.
11. Otherwise, if you only require a PDF that you can email or print via the a normal printer you can go to the PAS-LIVE – click on the Open book icon along the top menu, find the race and on the far right Click on the people icon. Click the Yellow box icon and this will open the secure PDF Basket list for printing.

Once the pigeons have been liberated, the Club Responsible needs to log in to the PAS-ADMIN and click on Club Admin – Races – and then click on the green arrow, amend the release time and start race. The race is now live.

RACE Readout

1. The PASBOX information will automatically be sent to the PAS-LIVE when clocked.
2. At clock reading, following instructions 1-8 above in PASCLUB synchronization.
3. Go to the read-out icon on the PASCLUB Master click OK
4. If the clock is a Bricon SPD,SPX, SPXXL, connect via the top docking port as normal and follow the instructions.
5. For PASBOX press OK and choose the fancier.
6. For other brands of ETS via Unives Press 2 connect the cable via the Port on the side and follow the instructions.
7. Once the clock has deactivated press 7 and print however many copies of the print out you require via the parallel printer.
8. Alternatively, if you only require a PDF that you can email or print via the a normal printer you can go to the PAS-LIVE – click on the Open book icon along the top menu, find the race and on the far right Click on the people icon. Click the green box icon and this will open the secure PDF Read out list for printing.

- 9 One the pigeons are race marked if you click on the people icon for the race the distances for each fancier can be added. This must be done before race closing.
- 10 Once the Bricon SPD, SPX, SPXXL have printed out a readout the connect the clock directly to the power and delete the race via the erase button. **ONLY DO THIS ONCE ALL RACES** have been read out.